



Solid *Application* Sheet

ALL-IN-ONE ODOR TREATMENT

Truth - Application / Directions

1. Make sure AC outlets are open.
2. Start vehicle and adjust Climate Controls so that the A/C system is ON.
3. Set the A/C system to **external** air vents (OUT SIDE AIR) and NOT "Recirculate."
4. Set AC Temperature to a Cool Setting.
5. CLOSE ALL DOORS / WINDOWS UP
6. Place the tip of the Universal Misting Gun into the air-intake vents located in the cowl (**lower windshield/hood**) area on the **exterior** of the vehicle. Depress the trigger and allow product to evacuate. Fog should be observed exiting the HVAC outlets near the dash. Continue fogging until approximately $\frac{1}{4}$ of the bottle (**2 ounces/first hash mark**) is used (**approximately 30 seconds**). Turn the vehicle off.



DO NOT sit inside vehicle during this and the remaining steps of the procedure. Stand outside vehicle while applying product.

1. Turn key "ON", **ignition "OFF"**.
2. Close all the A/C outlets located around the dashboard of the vehicle except the one closest to the driver's door.
3. (Standing Outside Door Open) Place the tip of the Universal Misting Gun into the open outlet. Depress the trigger and allow product to circulate through the A/C system until fog is observed exiting the A/C outlets near the dash, approximately **15 seconds**.
4. Close the outlet and move to the outlet closest to the front passenger door.
5. Open the outlet and repeat the previous step by circulating product throughout the A/C system for an **additional 15 seconds**.
6. (If Applicable) spray the rear air system outlets for approximately **5 seconds**.

Open all A/C outlets.

1. Start the vehicle
2. Adjust Climate Controls / A/C system is "ON" and fan is set on "LOW".
3. Set AC Temperature to a Cool Setting.
4. Set system to "RECIRCULATE" and not "EXTERNAL AIR."
5. Roll down the front and rear driver-side windows so there is approximately a **2" inch gap**.
6. Before closing the doors, spray the under-seat areas and headliner for a **few seconds**, making sure the spray tip is at least 6 inches from any surface.
7. Close the doors.
8. Insert the tip of the Universal Misting Gun inside the gap of the front window. Spray the front interior fabric, carpet and leather surfaces **in a sweeping motion** while using caution not to "saturate" any particular area. Spray until half the remaining product is used.
9. Switch to the rear window and repeat the previous step until the remaining product in the bottle is evacuated. Quickly open the driver door, close the window gaps and close the door.

Do not enter vehicle or open doors. (KEEP VEHICLE RUNNING) (AC ON / RECIRCULATE)

Allow product "fog" to circulate throughout the vehicle for **10 minutes**. Open the driver door. Turn vehicle "OFF." Roll down all windows. . If needed, wipe product residue from interior hard surfaces with a clean, dry towel. Customer is ready... You may leave windows down for 15 to 30 minutes after application to allow residual product to dissipate from vehicle