



Installation Instructions for Automotive A/C Treatment



1. With the engine running set the A/C Controls to maximum position



2. Attach the appropriate hose with a retracted piercing valve to the installation can



3. Attach the other end to the suction port and loosen can slightly to remove air .



4. Retighten can and turn the can upside down (valve down)



5. Puncture the can with the piercing valve. Open the valve and allow 1-2 minutes for installation.



6. Close the piercing valve and remove the hose from the suction port. Replace suction port cover.



7. Leave the empty can attached to the hose to prevent contamination of hose. The installation is complete.

If you are installing a dual evaporator system you will need to install 2 cans to get the proper amount for the system.

Drive the vehicle for 150 miles to allow the treatment process to fully complete.